

2011 Peterstown #2, WV
Site #: 204LS
Crew #: 04

Neighbor: *Sample Homeowner*
Route 1, Box 63
Lindside, WV 24951-
(888) 732-2492



DRIVING DIRECTIONS

1. Be sure to check in at the tool room before leaving the school to pickup any last minute tools and materials.
2. Depart from the High School by turning right onto CR 219/17 (Coulters Chapel Road) and proceeding 0.4 miles to US 219.
3. Turn right onto US 219 and proceed 0.2 miles to CR 25 (Cook Run Road).
4. Turn right onto CR 25 (Cook Run Road) and proceed 4.6 miles to Pond Ridge Road.
5. Turn left onto Pond Ridge Road and follow the gravel driveway past the front of the garage and to the left to the worksite at the top of the driveway.

House Description: *A single story bright blue house with white trim.*

EXTERIOR WORK PROJECTS

1. Paint

Project Status _____

1. When using ladder, refer to safety sheet on proper ladder usage. Be careful of overhead electric wires when painting. Read and understand all handouts on painting and caulking before beginning.
2. Use drop cloths to protect plants, flowers, concrete, and other objects as needed. This will reduce your clean-up time at the end of each day.
3. Scrape all loose paint in the areas you are painting. Use a water bottle to wet the paint before scraping. Some houses may contain lead-based paint and therefore all workcampers should wear goggles and masks when scraping. Lay plastic on the ground when scraping to catch all paint chips. Throw away the plastic every night to avoid exposure.
4. Caulk around all windows and doors of home.
5. Prime all bare wood and/or concrete. You don't need to prime the entire house, just the areas where bare wood is showing through.
6. Paint the house Respite.
7. When painting the trim of the house, be sure to have nice distinct lines. A steady hand and detailed eye are keys to painting trim. Paint the trim of the house White.
8. Install new fascia boards on home where needed. Prime and paint the new fascia White.
9. Install new 1/4" plywood to replace the rotten or missing soffit. Prime and paint the new soffit NEED COLOR.

Materials:

Exterior latex primer	Exterior latex paint - satin Respite
Exterior latex paint - satin White	Drop cloths
Caulk	2x4x10' regular lumber
1/4" AC plywood	

2. Porch Front Porch

Project Status _____

1. Refer to safety sheet before using power tools. Use a mask and goggles when cutting any pressure treated
2. Use the 4x4 posts to jack up the porch roof while you do the repairs listed below to the porch.
3. Remove old porch flooring.
4. Replace the rotten band board with a new 2x10.
5. Use 5/4" x 6" bull nose for decking. Space the decking using a 16d nail, but fasten them down with 8d or 10d nails.
6. When finished with the porch repairs, put the roof back to its original position. Return the un-cut 4x4's to the tool room.

Materials:

5/4x6x12' pressure treated	2x10x8' pressure treated
10d galvanized nails	

3. Porch Right Side Porch

Project Status _____

1. Refer to safety sheet before using power tools. Use a mask and goggles when cutting any pressure treated
2. Use the 4x4 posts to jack up the porch roof while you do the repairs listed below to the porch.
3. Remove old porch flooring.
4. Replace the posts with new 4x4's.
5. Use 5/4" x 6" bull nose for decking. Space the decking using a 16d nail, but fasten them down with 8d or 10d nails.
6. When finished with the porch repairs, put the roof back to its original position. Return the un-cut 4x4's to the tool room.

Materials:

Floor anchors for a 4x4 post
4x4x10' pressure treated

5/4x6x8' pressure treated
10d galvanized nails

INTERIOR WORK PROJECTS

1. Floor Laundry Room

Project Status _____

1. Refer to safety sheet when using power tools.
2. There is a weak section of flooring in the laundry room.
3. Remove the existing floor covering and make the floor as smooth as possible.
4. Use power saw to cut out the rotten floor section. Inspect the floor joists to make certain that all the joists are sound.
5. Replace or repair floor joists as needed to strengthen the floor. Use 2 x 6 scraps for nailers if needed.
6. Replace cut out section of flooring with new flooring.
7. Use floor leveling compound to seal all cracks and holes before laying the new floor covering. Also, sweep the area thoroughly.
8. Install new floor covering on the floor.

Materials:

Qt floor leveler
3/4" CDX plywood
16d galvanized nails

8d galvanized nails
2x6x8' regular lumber

2. Paint Kitchen

Project Status _____

1. Refer to ladder safety sheets before working on ladders. Be sure to work in a well-ventilated area when scraping and painting. Open windows and use fans to circulate the air.
2. Use masking tape to protect any woodwork. Use drop cloths to cover floors and any other objects that should not get paint on them.
3. Clean well before and after painting. Be sure to clean all drips and splatters.
4. Paint the walls Country White.

Materials:

Masking tape - 3/4"
Drop cloths

Interior latex paint - semi-gloss Country White